CONNECTING A SIEMENS MINITEK TO A REDCAT, 855 OR 885 SYSTEM

Below appears advice from Siemens which Hear and Learn has tailored to suit connection to Lightspeed Classroom Sound Enhancement products.

FOR TECHNICAL SUPPORT PERTAINING TO SIEMENS DEVICES, CALL 1300 787 797 EXT2

miniTek



1 Telephone button
2 Stand-by/mute
3 on/off button
4 Audio source button
5 Volume up/volume down
6 Program change button

Tek Transmitter



1 On/off switch
2 Sound level button
3 Socket for power plug
4 2.5mm stereo socket
5 LED

Charging the transmitter

You will need to charge the transmitter before first use.

Connect the transmitter with the power plug to a power supply. While charging the LED shines red.

Note: Charging time is about 5 hours depending on the status of the rechargeable battery.

Turning the transmitter on/off

Use the on/off switch on the transmitter to turn the transmitter on. The LED flashes blue while searching for a connection to the miniTek, then the LED shines blue.

Note: to turn the transmitter off, use the on/off switch. Turn the transmitter off when it is not in use.

Changing the sound level on the transmitter

Press the sound level button on the transmitter to change the volume of the audio signal. The LED flashes blue. The number of times the LED flashes (up to 5), indicates the volume level.

Using the transmitter

Press the on/off button on the miniTek for about 3 seconds to turn miniTek on.

Turn the transmitter on with the on/off switch.

Use the 3.5 mm male plug to 3.5 mm male plug cable supplied with the minitek - shown below - to connect to the ALD output on the Hear and Learn RedCAT or Hear and Learn 855 or 885 devices.





Hear and Learn RedCAT



Hear and Learn 855 or 885

Connect the transmitter with the power plug to a power supply or charge the rechargeable battery regularly.

Press the Audio source button on miniTek to change to the audio program.

The Audio source button on the miniTek flashes while searching for a connection to the transmitter and shines constantly after it is established. The LED on the transmitter confirms that the Bluetooth audio link is established.

Start the audio transmission on your TV or stereo. You can now hear the sound from your TV or stereo through your hearing instruments.

Note: You can use a second transmitter, which is available as an accessory. This way the first transmitter can always remain connected to your preferred device while the second transmitter is connected with another device (e.g. a second TV in your bedroom).

Note: This document is to be used as a guide only for the miniTek, outlining the basic layout and functionality of the device. In order to view a detailed and conclusive list of operating procedures and warnings relating to the device, please refer to the official user guide.